

DPA Hydraulic Heads



HYDRAULIC HEADS	SECTIONS	C	E	F	G	H	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	SOLENOID
7167-349	2															S							
7139-235	3	C								M	N				R	S							
9094-375	3															S							LATERAL
7139-709	3																T			W			
7180-611	3																			W			
7139-764	3															S	T	U					
7180-616	3						J									S	T						
9002-020	3															S							
9003-083	3															S		U					
9094-404	3															S	T						DOWN
9094-750	3									M													
9002-226	4									M													UP
7123-340	4		E	F	G		J	K	L	M					R	S	T	U		W			
7180-668 (MEFIN 7180-19)	4				G										R	S		U		W			LATERAL
7180-550	4				G													U					
7139-130	4																T						
7167-326	4						J																
7167-334	4									M						S	T	U					
9094-47	4																T						DOWN
9002-232	4							L															UP
7180-578 (MEFIN7123-359)	4									M													
7139-422	4																			W			
9045-462	4																	U					
7150-555	4				G																		
7180-675	4																			W			LATERAL
7180-698	4																	U					DOWN
9094-10	4															S							
9094-61	4										N												DOWN
9094-147	4										N												
9094-412	4																T						LATERAL
9094-416	4																T						DOWN
9094-417	4																	U					DOWN
7180-759 (MEFIN9094-425)	4																			W			
7123-345	6									M	N					S	T	U		W	X		
7180-559	6																	U			X		
7123-909	6																T	U	V				
7139-360	6																	U					
7180-139	6																T						
9002-071	6															S	T	U					
9003-135	6																	U					
7180-572	6																					Y	
9094-161	6																	U					DOWN

TYPE	A	C	E	G	I	L	N	Q	S	U	W	Y	RIGHT
	-	B	D	F	H	K	M	P	R	T	V	X	LEFT
Æ	4.5	5	5.5	6	6.5	7	7.5	8	8.5	9	9.5	10	